




Position Sensors WS10EX, WS12EX

Installation and operation manual



Please read carefully before installation and operation! Save these instructions for future reference.

POSIWIRE® EX Installation and operation manual




Contents	Marking of the sensor	3
	Safety Instructions	4
	Intended use	5
	Usage and description	6
	Delivery / Shipment	7
	Installation	15
	Operation	15
	Outline drawings	11
	Connection	13
	Dismounting	15
	Maintenance	17
	Service	17
	Calibration	18
	Disposal	18
	Declaration of Conformity	19

R

POSIWIRE® EX Installation and operation manual

Marking	Marker:		
WS II 3 D tc IIIC T80	WS10EX	€ II 3D E	x tc IIIC T80°C Dc X
	WS12EX	🖾 II 3D E	x tc IIIC T80°C Dc
	$3 = Dang$ $D = appli$ $tc = Prote$ $IIIC = cond$ $T80^{\circ}C = The$	luctive dust	22; D = dust sure: dust, zone 22 ved housing temperature is 80 °C (+176 °F)
	Ambient temp	erature:	-20 °C +40 °C -4 °F +104 °F
	Year of constr	uction:	2016



POSIWIRE[®] EX Installation and operation manual



Safety instructions

If total failure or malfunction of the sensor can cause danger or injury to the operator or damage to the machinery or equipment it is recommended that additional safety measures should be incorporated into the system.



Any alteration, reconstruction or extension of the sensor is not allowed.

Sensor must be operated only within values specified in the datasheet.

Connection to power supply must be performed in accordance with safety instructions for electrical facilities and performed only by trained staff.

Do not connect or disconnect the sensor under tension!

Disregard of this advice can lead to malfunctions, damage to property or personal injury and releases the manufacturer from product liability.



Do not open sensor

Release of spring under tension can result in injury!

Do not let snap the cable

 Uncontrolled cable retraction can break off cable fixing (cable clip or M4 connection). Broken cable fixing and cable can result in injury. Also sensor will be damaged!

Do not travel over range

• Uncontrolled cable retraction can result in injury. Also sensor will be damaged!



Do not exceed maximum operating voltage listed in the catalog

Risk of injury. Sensor will be damaged!

Avoid shocks to sensor case

• Sensor may be damaged!

POSIWIRE[®] EX Installation and operation manual



Intended use	The cable extension sensor was intended for linear position measurement via the extension of the measurement cable, when used in the properly rated ambient explosive atmospheric conditions for which the sensor is designated.
Unintended use	The unintended use is when the application has an explosive gas atmo- sphere or higher explosive dust atmosphere that requires a higher rated device.
	Do not use the sensor in the following environmental conditions:

- abrasive dust e.g. dust including metal or metaloxid, stone dust, glas dust, ceramic dust
- corrosive and aggressive media e.g. atmosphere with content of chloride.

POSIWIRE[®] EX Installation and operation manual



Usage and Description	 The purpose of position sensors is to transform position of a linear and guided movement into an electrical signal. Specifications of measuring range, environment, handling and connections as specified in the catalog, must be followed. The catalog is part of this instruction manual. If the catalog is not available it may be requested by stating the respective model number. The Operating Principle Linear motion of the measuring cable (flexible stainless steel) is converted into rotation by means of a precision cable drum. A spring motor provides torque for the cable retraction. Special design assures precise and reproducible winding of the measuring cable. Cable extraction or retraction is transformed into an electrical signal. Depending on application different sensing elements are used. Optional: Subsequent signal conditioners convert the signal of the sensing element into voltage, current, or digital pulses suitable for standard interfaces.				
	Measurement Signal and Range				
	Measurement signal: Analog, not adjusted Potentiometer Sensitivity not adjustable		Resistance range is 3% to 98%. 0% or 10 sible. Individual sensi on the label.	00% are not pos-	
	Analog, adjusted Integrated signal condition Sensitivity adjusted	ner	Measuring range con electrical measuring r (e.g. 4 20 mA).		
	Output Actual position	0 % 0 mm	30 % 300 mm	100 % 1000 mm !	
	Potentiometer (e.g. 1 kΩ)	approx. 3 %	approx. 30 %	approx. 98 %	
	Integrated signal conditioner (e.g. 4 20 mA)	 0 % 4 mA	 30 % 8,8 mA	100 % 20 mA	
	Incremental encoder (e.g. 10 pulses/mm)	0 %	30 % 3000	 100 % 10000	
		3	Measurement range		

POSIWIRE[®] EX Installation and operation manual



Option cable dust wiper SAB2	A seal which minimizes the ingress	of dust into the sensor.
Delivery/ Shipment	Unpacking	Do not unpack sensor by pulling cable or cable clip.
	Shipment damages	Check sensor immediately for shipping damage.
	contact supplier or ASM GmbH Mod	ent not operating appropiately, please osinning. To avoid shipment damages, original packing for further shipment.
Return consignment	Return consignment for calibration of (Return Material Authorization). Plean number:	or repair: only with the RMA number ase contact ASM and request the RMA
	ASM Automation Sensorik Messtech Service&Repair	nnik GmbH
	Am Bleichbach 18-24 D-85452 Moosinning	
	Tel. +49 8123 986-0 Fax +49 8123 986-500	
	service@asm-sensor.de www.asm-sensor.com	

POSIWIRE[®] EX Installation and operation manual



Installation



Explosion Risk! Installation may only be performed when no explosive atmospheric conditions are present.



General information

- Install the sensor according to the specifications of the manufacturer and the valid standards and directives
- Please note the installation and safety instructions of the instruction and reference manual
- Do not operate the sensor outside of the electrical, mechanical and thermal parameters
- Crossing the dew point must be avoided
- During installation no explosive atmosphere may be present



Cable shall be properly secured and protected against damage. Cable shall be protected from UV-radiation! Installation according to DIN EN 60079-14. Dust deposits are to be avoided! Do not mount the sensor in the dust particle stream! Protect the sensor against damage! The housings have been examined with the impact energy DIN EN 60079-1 for WS10EX: 4 Joules, WS12EX: 7 Joules. The sensor, the wire shield and the wire must be connected to the local potential equalizer.

The connection cross-section of the sensor must be at least 4 mm².

POSIWIRE[®] EX Installation and operation manual




Installation



Measuring cable

Do not damage cable! Cable must not be oiled or lubricated! Do not snap cable! Do not travel over range! Do not kink cable! Cable travel should be axial to the cable outlet - no misalignment allowed! Do not drag cable along objects!





Precautions

Do not let snap the cable fixing clip

Uncontrolled retraction of cable may damage sensor. No warranty will be granted for snapped cables.

Mounting hints for unfavourable conditions

If possible fasten cable fixing with cable in retracted position. For example, fit a mounting loop (see diagram) and put it around your wrist. Do not remove the mounting loop before the cable ist fastened. The cable clip may be opened for easy attachment.

Mounting

To ensure proper operation, install the sensor only as described in this manual.

Installation position

<u>Covered or shielded travel</u> of cable is preferred.	This prevents cable from damage, soiling and manipulation.
Cable outlet is preferred pointing downwards.	Soaking of liquids into the cable outlet is impossible, concentration of condensing water will be avoided.
Fit sensor on <u>plain base</u> or use <u>three-</u>	This prevents sensor from bending

Fit sensor on <u>plain base</u> or use <u>three-</u> Th <u>point mounting</u> on uneven surfaces. an

This prevents sensor from bending and damage.

POSIWIRE® EX Installation and operation manual



Installation





Cable travel should only be axial to the cable outlet - no misalignment is allowed.

Cable misalignment shortens service life of sensor and causes error in measurement. Warranty will not be granted for damage caused by misalignment.

If cable travel axial to the cable outlet is not possible, the cable guide wheel SR2 (accessories) must be used in order to turn the cable.

For special applications extension cables with clips on both ends are available.

Fitting the sensor

Depending upon the sensor model, drillings in the base plate, threads or T-slots in the sensor housing enable attachment of the sensor. Dimensions required are listed in the catalog.

Cable attachment device

For fastening the cable clip SB0 the following solutions are available. For example:

a) Set screw M5:	Standard fixing.
(Allen screw)	
b) Attachment head GK1/GK2:	Fast cable attachment, easy to
(accessory)	remove.
c) Magnetic clamp MAG1:	An easy way to fasten the cable to
(accessory)	ferromagnetic materials.




The mounting of the M4 connection is made with a through hole and a M4 nut. <u>Note:</u> Do not screw the M4 connection itself into a stationary object, otherwise the measuring cable will be twisted!

Cable clip attachment

When fastening the cable clip take notice of the chapter *Installation / Pre-cautions* (page 9).

POSIWIRE® EX Installation and operation manual





A – Optional cable clip SB0

B – M5 - 8 [.315] deep

Dimensions in mm [inch]


C = Connection for potential equalization


Model	Screw	Material	Torque [Nm]
WS10EX	M5, 8 mm deep	A2	2.0

POSIWIRE® EX Installation and operation manual




Outline drawing WS12EX





Option SB0



	Model	Screw	Material	Torque [Nm]
in mm [inch]	WS12EX	M5, 10 mm deep	A2	2.0

	Range	Α	В	С	D	Е	F	F*
Dimensions in mm	100; 500; 1000	18.3	137	14	43	71	141	154
	125; 1250	14.5	137	14	43	71	141	154
	1500	10.7	152	14	43	71	141	154
	2000	21.5	152	15	79	109	179	192
	2500	13.3	152	15	79	109	179	192
	3000	9.2	152	15	79	109	179	192

12 MAN-WSEX-E-16

Dimensions i

© by ASM GmbH

SUNSTAR自动化 http://www.sensor-ic.com/ TEL: 0755-83376489 FAX:0755-83376182 E-MAIL:szss200163.com www.asm-sensor.com

POSIWIRE® EX Installation and operation manual




Connection

Connect the cable according to the following tables.

Voltage divider R1K	Excitation voltage	24 V DC (max. 32 V DC at 1 k Ω , max. power 1 W)
Potentiometer	Potentiometer impedance	1 kΩ ±10 %
	Thermal coefficient	±25 x 10 ⁻⁶ / °C f.s.
	Sensitivity	Depends on the measuring range, individual sensitivity of the sensor is specified on the label
	Voltage divider utilization range	Approx. 3 % 97 %
	EMC	According to DIN EN 61326-1:2013

Output signals






V DC)

Signal conditioner 10V	Excitation voltage	24 V DC non stabilized, (18 27 V I
Voltage output	Excitation current	20 mA max.
	Output voltage	0 10 V DC
	Output current	2 mA max.
	Output load	> 5 kΩ
	Stability (temperature)	±50 x 10 ⁻⁶ / °C f.s.
	Protection	Reverse polarity, short circuit
	Output noise	0.5 mV _{RMS}
	EMC	According to DIN EN 61326-1:2013

Output signals



Signal wiring	Signal name R1K	10V	Cable color
	+Vin	Excitation +	white
	GND	Excitation GND	brown
	+Vout	Signal +	green
		Signal GND	yellow


Cable: UL / cUL - LIYCY 8xAWG24 Style 2464/1061

POSIWIRE® EX Installation and operation manual



Connection	Connect the cable according	g to the following tables.
Signal conditioner	Excitation voltage	24 V DC non stabilized (12 27 V DC), measured at the sensor terminals
420A	Excitation current	35 mA max.
Current output (2 wire)	Output current	4 20 mA equivalent for 0 100 % range
	Stability (temperature)	$\pm 100 \times 10^{-6}$ / °C f.s.
H mA	Protection	Reversed polarity, short circuit
	Output noise	0.5 mV _{RMS}
	EMC	According to DIN EN 61326-1:2013
Output signals	420A 420 mA	Signal + Signal –
Signal conditioner 420T	Excitation voltage	24 V DC non stabilized, (18 27 V DC)
	Excitation current	40 mA max.
Current output (3 wire)	Load resistor	350 Ω max.
↓ ↓ ↓ mA	Output current	4 20 mA equivalent for 0 100 % range
	Stability (temperature)	±50 x 10 ⁻⁶ / °C f.s.
	Protection	Reverse polarity, short circuit
	Output noise	0.5 mV _{RMS}
	EMC	According to DIN EN 61326-1:2013

Output signals



Signal wiring	Signal name 420A	420T	Cable color
	Signal +	Excitation +	white
	Signal –	Excitation GND	brown
		Signal +	green

Cable: UL / cUL - LIYCY 8xAWG24 Style 2464/1061

POSIWIRE[®] EX Installation and operation manual




Installation

Connection example: current output 420A

To convert the 4 ... 20 mA signal into a voltage signal, it needs a load resistor $R_{_M}$ (measuring resistor) as shown in the diagram. The maximum value of $R_{_M}$ depends on the cable resistance $R_{_L}$ and the excitation voltage $U_{_B}$:

$$R_{Mmax} = ((U_{B} - 12 V)/0.02 A) - R_{L}$$

With an excitation of 24 V DC and a cable resistance R_L = 500 Ω a maximum value of R_M = 100 Ω can be used.



Operation

Ambient temperature: Maximum cable speed: -20°C up to 40°C v_{max} = 2m/s

Do not use the sensor in the following environmental conditions:

- abrasive dust e.g. dust including metal or metaloxid, stone dust, glas dust, ceramic dust
- corrosive and aggressive media e.g. atmosphere with content of chloride.

The unintended use is when the application has an explosive gas atmosphere or higher explosive dust atmosphere that requires a higher rated device.

POSIWIRE® EX Installation and operation manual



Dismounting



Explosion Risk! De-installation may only be performed when no explosive atmospheric conditions are present.



Precautions

Do not let snap the cable fixing clip Uncontrolled retraction of cable may damage sensor. No warranty will be granted for snapped cables.



Measuring cable

Do not damage cable! Do not kink cable! Do not drag cable along objects!

Disconnect electrical connections.

Disconnect measurement cable and slowly guide it back into the sensor housing.

De-install sensor.

POSIWIRE[®] EX Installation and operation manual



Maintenance

Maintenance interval: The measurement cable must be replaced at the latest 100 000 operation cycles. One operation cycle consist of a movement set including a turnaround



Explosion Risk! Maintenance may only be performed when no explosive atmospheric conditions are present.

	Check for dust deposit	Integrity of housing	Integrity of connector, cable	Mounting elements	Cable
WS10EX	x	x	x	х	x
WS12EX	x	x	x	х	x
Activity	Dust deposit: Remove dust	Damaged parts: Put sensor out of service Send sensor to ASM for repair	Damaged parts: Put sensor out of service, replace dama- ged parts resp. send sensor to ASM for repair	Loose mounting parts: Screw tight moun- ting parts with re- commended torque, if applicable use bolt adhesive	Damaged cable, spliced or ben- ded cable: Send sensor to ASM for repair

	Cable dust wiper SAB2
WS10EX	×
WS12EX	x
Activity	Dust deposit: clean the sensor and check the wear, replace damaged parts resp. send sensor to ASM for repair

R

POSIWIRE® EX Installation and operation manual

Calibration	The recommended calibration interval is 1 year.
	Test protocol and traceable calibration certificate (ISO9001 / ISO10012) is available on request.
Electromagnetic Compatibility (EMC)	The electromagnetic compatibility depends on wiring practice. Recommen- ded wiring:
	 Use shielded twisted pair sensor cable. Ground shield single ended at switch cabinet. Connect shield directly before or at cable inlet of switch cabinet by low impedance ground cable bond. On delivery of preassembled sensor cables the shield is not connected to the sensor housing. Keep sensor signal well separated from power wiring e.g. AC wiring, motor or relay. Use separate conduit or ducts for each.
	If application includes highly electromagnetic interference emitting equip- ment like switch converter drives additional measures are recommended:
	 Use a twisted pair cable, shielded per pair and common. Use shielded conduits or ducts connected to ground potential.
Repair and	Sensors and accessories have to be repaired and adjusted at ASM in



Moosinning.

In order to avoid risk of injury and improper handling do not try to repair. No warranty or liability will be granted for opened sensors. Damaged sensors must be shut down immediately and sent to the factory for repair.

Send metal parts for recycling! Disposal according to applicable government regulations.

POSIWIRE[®] EX Installation and operation manual



EU Declaration of Conformity

We

ASM GmbH Am Bleichbach 18 - 24 D-85452 Moosinning

Declare under our sole responsibility that the product

Name:Position sensorType:WS10EXII 3D Ex tc IIIC T80°C Dc XWS12EXII 3D Ex tc IIIC T80°C DcOptions:- R1K, - 10V, - 420A, - 420T

to which this declaration relates is in conformity with the following standards or other normative documents:

Directives:	2004/108/EG (EMC)
	94/9/EG (up to 19th April 2016)
	2014/34/EU (from 20th April 2016)

Standards: EN 61326-1:2013 EN 60079-1 (June 2014) EN 60079-31 (December 2014)

Moosinning, 15th February 2016

i. A. Keup

p.p. Dr.-ing. Gunnar Kamp Head of Mechanical Engineering

p.p. Peter Wirth Head of Development

ASM GmbH Automation • Sensorik • Messtechnik Am Bleichbach 18-24 Telephone: +49 8123 986-0 Internet: www.asm-sensor.com E-Mail: info@asm-sensor.de



© by ASM GmbH, Moosinning 5.2.0 / 02.2016 Subject to change without notice. See protection note DIN 34!

SUNSTAR自动化 http://www.sensor-ic.com/ TEL: 0755-83376489 FAX:0755-83376182 E-MAIL:szss20@163.com