MOTOROLA

Automotive Direction Indicator


The MC33193 is a new generation industry standard UAA1041 "Flasher". It has been developed for enhanced EMI sensitivity, system reliability, and improved wiring simplification. The MC33193 is pin compatible with the UAA1041 and UAA1041B in the standard application configuration as shown in Figure 9, without lamp short circuit detection and using a 20 m Ω shunt resistor. The MC33193 has a standby mode of operation requiring very low standby supply current and can be directly connected to the vehicle's battery. It includes an RF filter on the Fault detection pin (Pin 7) for EMI purposes. Fault detection thresholds are reduced relative to those of the UAA1041, allowing a lower shunt resistance value (20 m Ω) to be used.


- Pin Compatible with the UAA1041
- Defective Lamp Detection Threshold
- RF Filter for EMI Purposes
- Load Dump Protection
- Double Battery Capability for Jump Start Protection
- Internal Free Wheeling Diode Protection
- Low Standby Current Mode




AUTOMOTIVE DIRECTION INDICATOR

SEMICONDUCTOR TECHNICAL DATA







ORDERING INFORMATION

Device	Operating Temperature Range	Package
MC33193D	$T_{\Delta} = -40^{\circ}$ to $125^{\circ}C$	SO-8
MC33193P	$T_{A} = -40$ to 125 C	DIP-8

© Motorola, Inc. 1998

SUNSTAR传感与控制 http://www.sensor-ic.com/ TMGG33193649 FAX:0755-83376182 E-MAIL:szss20@163.com


MAXIMUM RATINGS

Rating	Symbol	Value	Unit
Pin 1 Positive Current (Continuous/Pulse)	11+	150 to 500	mA
Pin 1 Negative Current (Continuous/Pulse)	l1–	-35 to -500	mA
Pin 2 Current (Continuous/Pulse)	12	l2 ±350 to ±1900	
Pin 3 Current (Continuous/Pulse)	13	±300 to ±1400	mA
Pin 8 Current (Continuous/Pulse)	18	±25 to ±50	mA
ESD (All Pins Except Pin 4 for Negative Pulse)	V _{ESD}	±2000	V
ESD (Pin 4 Negative Pulse)	V _{ESD4-}	-1000	V
Junction Temperature	ТJ	150	°C
Operation Ambient Temperature Range	т _А	-40 to 125	°C
Storage Temperature Range	T _{stg}	-65 to 150	°C

NOTE: ESD data available upon request.

ELECTRICAL CHARACTERISTICS ($-40^{\circ}C \le T_A \le 125^{\circ}C$, 8.0 V $\le V_{CC} \le 18$ V, unless otherwise noted. Typical values reflect approximate mean at $T_A = 25^{\circ}C$, $V_{CC} = 14$ V at the time of initial device characterization.)

Characteristic	Symbol	Min	Тур	Max	Unit
Battery Voltage Range (Normal Operation)	Vb	8.0	-	18	V
Overvoltage Detector Threshold (VPin2 - VPin1)	Vih	19	20.2	22	V
Clamping Voltage (R2 = 220 Ω)	V _{cl}	27	29.2	34	V
Output Voltage [I = -250 mA (V _{Pin2} - V _{Pin3})]	V _{sat}	-	-	1.5	V
Starter Resistance (R _{st} = R2 + R _{Lamp})	R _{st}	-	3.3	3.6	kΩ
Oscillator Constant (Normal Operation, $T_A = 25^{\circ}C$)	K _n	1.3	1.5	1.75	Х
Temperature Coefficient of Kn	TC _{Kn}	-	0.001	-	1/°C
Duty Cycle (Normal Operation)	-	45	50	55	%
Oscillator Constant (One 21 W Lamp Defect, $T_A = 25^{\circ}C$)	Kf	0.63	0.68	0.73	Х
Duty Cycle (One 21 W Lamp Defect)	-	35	40	45	%
Oscillator Constant ($T_A = 25^{\circ}C$)	K1 K2	0.167 0.250	0.180 0.270	0.193 0.290	-
Standby Current (Ignition "Off")	ICC	-	2.0	100	μA
Current Consumption (Relay "Off," Enable Pin 6 High) $V_{bat} = 8.0 V, R3 = 220 \Omega, T_A = 25^{\circ}C$ $V_{bat} = 13.5 V, R3 = 220 \Omega$ $V_{bat} = 18 V, R3 = 220 \Omega, T_A = 25^{\circ}C$	Icc		1.40 2.16 2.64	_ 3.5 _	mA
Current Consumption (Relay "On") $V_{bat} = 8.0 \text{ V}, \text{ R3} = 220 \Omega, \text{ T}_{\text{A}} = 25^{\circ}\text{C}$ $V_{bat} = 13.5 \text{ V}, \text{ R3} = 220 \Omega$ $V_{bat} = 18 \text{ V}, \text{ R3} = 220 \Omega, \text{ T}_{\text{A}} = 25^{\circ}\text{C}$	Icc		1.62 2.06 3.30	_ 6.0 _	mA
Defect Lamp Detector Threshold [R3 = 220 Ω , (V _{Pin2} - V _{Pin7})] V _{bat} = 8.0 V, T _A = 25°C V _{bat} = 13.5 V V _{bat} = 18 V, T _A = 25°C	VS	- 46.5 -	43.6 51.0 57.0	- 56 -	mV
Temperature Coefficient of VS	TCVS	_	0.3 x 10 ^{−3}	_	1/°C



The MC33193 is designed to drive the direction indicator flasher relay. It is a new generation industry standard UAA1041 "Flasher". It consists of the following functions:

- Supply and Protections
- On-Chip Relay Driver
- Oscillator
- Starter Functions
- Lamp Fault Detector with Internal RF Filter
- Standby Mode

Supply and Protection Systems

Pin 1 is connected to ground via resistor R3 which limits the current in the event of any high voltage transients. Pin 2 (V_{CC}) is the positive supply and may be connected directly to the vehicle's battery voltage.

Overvoltage and Double Battery Protection: When the applied V_{CC} to V_{SS} voltage is greater than 22 V, the overvoltage detector circuit turns the relay driver off. Both the device and the lamps are protected if two 12 V batteries are connected in series and used to jump start the vehicle.

Load Dump Overvoltage Protection: A 29 V overvoltage detector protects the circuits against high voltage transients due to load dumps and other low energy spikes. The relay driver is automatically turned on whenever the V_{CC} to V_{SS} voltage is greater than 34 V.

Overvoltage Protection, High Voltage Transients: The Enable and the Starter pins are protected against positive and negative transients by internal on–chip diodes.

On–Chip Relay Driver

The device directly drives the flasher relay. The output structure is an Emitter of an NPN transistor. It contains the free wheeling diode circuitry necessary to protect the device whenever the relay is switched off.

Oscillator

The device uses a sawtooth oscillator (Figure 1).

The frequency is determined by the external components C1 and R1. In the normal operating mode, the flashing frequency is: $F_n = 1/R1^*C1^*K_n$. With a defective (open) 21 W lamp (Figure 2), the flashing frequency changes to: $F_n = 2.2^*F_n$.

The typical first flash delay (the time between the moment when the indicator switch is closed and the first lamp flash occurs) is: t1 = K1*R1*C1

The fault detection delay is from the time relay R1 is on and fault detection is enabled. Where a 21 W lamp opens, the delay is expressed as: $t2 = K2^*R1^*C1$

Starter

Pin 8 is connected through a $3.3 \text{ k}\Omega$ resistor to the flashing lamp. Pin 8 is the input to the Starter function and senses the use of S1 by sensing ground through the lamp (Figures 9 and 10).

Lamp Fault Detector with Internal RF Filter

A Lamp defect is sensed by the lamp fault detector's monitoring of the voltage developed across the external shunt resistor R_S via the RF filter. The R_S voltage drop is compared to a V_{bat} dependent internal reference voltage (V_{ref}) to validate the comparison over the full battery voltage range. A detected fault causes the oscillator to change frequency (Figure 2).

Standby Mode

When the ignition key and warning switches are open; Enable is in a low state and the internal switches, SW1 and SW2, are open and no current passes through the circuit. In this condition, the device's current consumption is zero ($I_{CC} = 0$). When ignition key and warning switches are closed; Enable is in a high state with SW1 and SW2 being closed and the circuit is powered on.

MAIN DIFFERENCES BETWEEN UAA1041B & MC33193

The MC33193 is pin compatible with the UAA1041.

Supply Current

Supply current is more stable on the MC33193 when the device is in "on" or "off" state. In "on" state the supply current is only 40% higher than when in the "off" state, as compared to a ratio of 3 times for the UAA1041. This results in a lower voltage drop across the ground resistor R3 (see On–Chip Relay Driver).

Short Circuit Detection

The MC33193 has no short circuit detection.

Standby Mode (Pin 6)

The UAA1041 has no standby mode. Pin 6 is used as an Enable/Disable for the short circuit detection.

The MC33193 uses Pin 6 to set the device in standby mode. If Pin 6 is connected to ground, the MC33193 is in the standby mode. In this mode, standby current is very low and Pin 8's starter resistor R2 and a 2.0 k Ω internal resistor are switched off. As soon as Pin 6 is at a high level (typical threshold = $2V_{be}$) the device becomes active. In the application, the MC33193 can be connected directly to the battery and awakened whenever Pin 6 is connected to the vehicle's battery by way of a protection resistor and the ignition key switch.

Lamp Defect Detection (Pin 7)

The UAA1041 operates with a 30 m Ω shunt resistor to sense the lamp current. It's lamp defect detection threshold of Pin 7 is typically 85 mV.

The MC33193 is designed to operate with 20 m Ω shunt resistor and at a reduced threshold of 50 mV. This reduces power generation in the flasher module. In addition, the MC33193 incorporates an RF filter to enhance RFI immunity.

Load Dump and Overvoltage Behavior


The UAA1041 and MC33193 both behave the same in this regard. Both have double battery detection and lamp turn–off protection in the event of a jump start. During load dump, both devices are protected by an internal 30 V zener diode with the relay activated during a load dump.

Relay Driver

Drive capability of both devices is the same. Free wheeling diode protection is internal to both devices. The free wheeling voltage is $2V_{be}$ for the UAA1041 and $3V_{be}$ for the MC33193. This results in a higher clamp voltage across the relay and thus in a faster turn–off. In addition, the lower "on" state supply current is lower on the MC33193 and thus the voltage drop across the ground resistor R3 is reduced. This results in an even higher clamp voltage across the relay.

Oscillator Phase

The oscillator phase is opposite on the MC33193 as compared to the UAA1041. The Oscillator voltage is falling during "on" state and rising during "off" state for the MC33193.







Figure 6. Output Voltage versus Temperature








Figure 9. MC33193 Typical Application



Application Information

NOTES: 1. In the above application, the MC33193 is compatible with the UAA1041 and UAA1041B except for the shunt resistor value ($R_S = 20 \text{ m}\Omega$). 2. The flashing cycle is started by the closing of switch S1. 3. The position of switch S1 is sensed across resistor R2 and R_{Lamp} by the input, Pin 8.


Figure 10. Typical MC33193 Application



Application Information

 $\ensuremath{\textbf{NOTES:}}$ 1. The flashing cycle is started by the closing of switch S1.

- 2. The S1 switch position is sensed across the resistor R2 and R_{Lamp} by the input (Pin 8). 3. If the logic state at Pin 6 is [0], the current through R2 is off.



OUTLINE DIMENSIONS

Motorola reserves the right to make changes without further notice to any products herein. Motorola makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Motorola assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters which may be provided in Motorola data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals" must be validated for each customer application by customer's technical experts. Motorola does not convey any license under its patent rights nor the rights of others. Motorola products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Motorola product could create a situation where personal injury or death may occur. Should Buyer purchase or use Motorola products for any such unintended or unauthorized application, Buyer shall indemnify and hold Motorola and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Motorola was negligent regarding the design or manufacture of the part. Motorola and the adverted for any such unintended or unauthorized use, even if such claim alleges that Motorola was negligent regarding the design or manufacture of the part. Motorola and the adverted or Motorola, Inc. Motorola, Inc. is an Equal Opportunity/Affirmative Action Employeer.

How to reach us:

USA/EUROPE/Locations Not Listed: Motorola Literature Distribution; P.O. Box 5405, Denver, Colorado 80217. 1–303–675–2140 or 1–800–441–2447

JAPAN: Nippon Motorola Ltd.; SPD, Strategic Planning Office, 141, 4–32–1 Nishi–Gotanda, Shinagawa–ku, Tokyo, Japan. 81–3–5487–8488

Customer Focus Center: 1-800-521-6274

MOTOROLA

 Mfax™: RMFAX0@email.sps.mot.com
 – TOUCHTONE 1–602–244–6609

 Motorola Fax Back System
 – US & Canada ONLY 1–800–774–1848

 – http://sps.motorola.com/mfax/

ASIA/PACIFIC: Motorola Semiconductors H.K. Ltd.; 8B Tai Ping Industrial Park, 51 Ting Kok Road, Tai Po, N.T., Hong Kong. 852–26629298

HOME PAGE: http://motorola.com/sps/



SUNSTAR自动化 http://www.sensor-ic.com/ TEL: 0755-83376489 FAX:0755-83376182 E-MAIL:szss20@163.com

Mfax is a trademark of Motorola, Inc.

SUNSTAR 商斯达实业集团是集研发、生产、工程、销售、代理经销、技术咨询、信息服务等为一体的高科技企业,是专业高科技电子产品生产厂家,是具有10多年历史的专业电子元器件供应商,是中国最早和最大的仓储式连锁规模经营大型综合电子零部件代理分销商之一,是一家专业代理和分銷世界各大品牌IC芯片和電子元器件的连锁经营综合性国际公司,专业经营进口、国产名厂名牌电子元件,型号、种类齐全。在香港、北京、深圳、上海、西安、成都等全国主要电子市场设有直属分公司和产品展示展销窗口门市部专卖店及代理分销商,已在全国范围内建成强大统一的供货和代理分销网络。我们专业代理经销、开发生产电子元器件、集成电路、传感器、微波光电元器件、工控机/DOC/DOM 电子盘、专用电路、单片机开发、MCU/DSP/ARM/FPGA软件硬件、二极管、三极管、模块等,是您可靠的一站式现货配套供应商、方案提供商、部件功能模块开发配套商。商斯达实业公司拥有庞大的资料库,有数位毕业于著名高校——有中国电子工业摇篮之称的西安电子科技大学(西军电)并长期从事国防尖端科技研究的高级工程师为您精挑细选、量身订做各种高科技电子元器件,并解决各种技术问题。

更多产品请看本公司产品专用销售网站:

商斯达中国传感器科技信息网: http://www.sensor-ic.com/

商斯达工控安防网: <u>http://www.pc-ps.net/</u>

商斯达电子元器件网: <u>http://www.sunstare.com/</u>

商斯达微波光电产品网:HTTP://www.rfoe.net/

商斯达消费电子产品网://www.icasic.com/

商斯达实业科技产品网://www.sunstars.cn/

传感器销售热线:

地址: 深圳市福田区福华路福庆街鸿图大厦 1602 室

电话: 0755-83370250 83376489 83376549 83607652 83370251 82500323

传真: 0755-83376182 (0) 13902971329 MSN: <u>SUNS8888@hotmail.com</u>

邮编: 518033 E-mail:<u>szss20@163.com</u> QQ: 195847376

深圳赛格展销部: 深圳华强北路赛格电子市场 2583 号 电话: 0755-83665529 25059422 技术支持: 0755-83394033 13501568376

欢迎索取免费详细资料、设计指南和光盘;产品凡多,未能尽录,欢迎来电查询。 北京分公司:北京海淀区知春路132号中发电子大厦3097号

TEL: 010-81159046 82615020 13501189838 FAX: 010-62543996

- 上海分公司:上海市北京东路 668 号上海賽格电子市场 2B35 号
 - TEL: 021-28311762 56703037 13701955389 FAX: 021-56703037

西安分公司:西安高新开发区 20 所(中国电子科技集团导航技术研究所)

西安劳动南路 88 号电子商城二楼 D23 号

TEL: 029-81022619 13072977981 FAX:029-88789382