


AHRS500GA Series Operator's Manual

Document 7430-0060-02
Revision A, December 2002



Crossbow

Crossbow Technology, Inc., 41 Daggett Dr., San Jose, CA 95134
Tel: 408-965-3300, Fax: 408-324-4840
email: info@xbow.com, website: www.xbow.com

Revision History

Revision	Date	Author	Comments
-01_A	9/16/02	JR	Initial Release
-02_A	12/02	DJ	Added limitation section, changed startup time to 90 seconds

©2001-2002 Crossbow Technology, Inc. All rights reserved. Information in this document is subject to change without notice.

Crossbow and SoftSensor are registered trademarks and AHRS500GA is a trademark of Crossbow Technology, Inc. Other product and trade names are trademarks or registered trademarks of their respective holders.

Table of Contents

1	Introduction.....	1
1.1	The AHRS500GA Series Motion and Attitude Sensing Units.....	1
2	Package Contents	2
3	AHRS500GA Description.....	3
3.1	AHRS500GA Coordinate System.....	3
3.2	Connections.....	4
3.2.1	I/O Cable	5
3.2.2	Power Input and Power Input Ground.....	5
3.2.3	Case Ground.....	5
3.2.4	Serial Data Interface	5
3.2.5	BIT Status Output Pin	6
3.2.6	Magnetometer calibration Input Pin	6
3.2.7	No Connection.....	6
3.2.8	Quick Digital interface connection	6
3.3	Measurements	7
3.3.1	Attitude and Heading.....	7
3.3.2	Sensor Measurements.....	8
3.3.3	BIT Processing	8
3.4	Commands.....	10
3.5	Data Packet Format.....	10
3.6	Timing.....	11
3.7	Magnetic Heading.....	11
4	AHRS500GA Operation.....	12
4.1	Normal Operation.....	12
4.2	Calibration Operation	12
4.3	Viewing AHRS500GA Data with GyroView	12
4.3.1	GyroView Computer Requirements.....	12
4.3.2	Install GyroView.....	12
4.3.3	Connections.....	12
4.3.4	Setup GyroView.....	13
4.3.5	Take Measurements	13
5	Limitations	15
5.1	Installation.....	15

- 5.2 Calibration 15
- 5.3 Operation 15
- 5.4 Range Limitations 15
- 6 AHRS500GA Installation..... 16
- 7 Appendix A. Mechanical Specifications..... 17
- 8 Appendix B. AHRS500GA Output Quick Reference 18
- 9 Appendix C. Hard and Soft Iron Calibration 19
 - 9.1 Hard/Soft Iron Calibration Requirements 19
 - 9.2 Hard/Soft Iron Calibration Introduction..... 19
 - 9.3 AHRS500GA Hard and Soft Iron Calibration Procedure 19
 - 9.3.1 Equipment Needed..... 20
 - 9.3.2 Installation and Calibration Cable Connections..... 20
 - 9.4 Calibration Process 21
 - 9.4.1 Starting the Calibration 21
 - 9.4.2 Switch to Mag Cal Mode 23
 - 9.4.3 Collecting Calibration Data 23
 - 9.4.4 Evaluating Calibration Data 25
 - 9.4.5 Completing the Calibration 27
 - 9.4.6 Testing the Calibration 27
- 10 Appendix D. Warranty and Support Information 28
 - 10.1 Customer Service 28
 - 10.2 Contact Directory 28
 - 10.3 Return Procedure 28
 - 10.3.1 Authorization 28
 - 10.3.2 Identification and Protection 29
 - 10.3.3 Sealing the Container 29
 - 10.3.4 Marking..... 29
 - 10.3.5 Return Shipping Address..... 29
 - 10.4 Warranty 29

About this Manual

The following annotations have been used to provide additional information.

◀ NOTE

Note provides additional information about the topic.

☑ EXAMPLE

Examples are given throughout the manual to help the reader understand the terminology.

🔖 IMPORTANT

This symbol defines items that have significant meaning to the user

💣 WARNING

The user should pay particular attention to this symbol. It means there is a chance that physical harm could happen to either the person or the equipment.

The following paragraph heading formatting is used in this manual:

1 Heading 1

1.1 Heading 2

1.1.1 Heading 3

Normal

1 Introduction

1.1 The AHR500GA Series Motion and Attitude Sensing Units

This manual explains the use of the AHR500GA Series of products, nine-axis measurement system designed to measure stabilized pitch, roll and yaw angles in a dynamic environment.

The AHR500GA is a nine-axis measurement system that combines linear accelerometers, rotational rate sensors, and magnetometers. The AHR500GA uses the 3-axis accelerometer and 3-axis rate sensor to make a complete measurement of the dynamics of your system. The addition of a 3-axis magnetometer also allows the AHR500GA to make a true measurement of magnetic heading.

The AHR500GA is the solid-state equivalent of a vertical gyro/artificial horizon display combined with a directional gyro.

The AHR500GA series units are low power, fast turn on, reliable and accurate solutions for a wide variety of stabilization and measurement applications.

All AHR500GA products have an RS-232 serial link. Data is streamed continuously.

Crossbow Technology AHR500GA units employ onboard digital processing to compensate for deterministic error sources within the unit and to compute attitude information. The AHR500GA units accomplish these tasks with an analog to digital converter and high performance Digital Signal Processors.

The AHR500GA uses angular rate sensors and linear acceleration sensors that are micro-machined devices. The three angular rate sensors consist of vibrating ceramic plates that utilize the Coriolis force to output angular rate independently of acceleration. The three MEMS accelerometers are surface micro-machined silicon devices that use differential capacitance to sense acceleration. Solid-state MEMS sensors make the AHR500GA both responsive and reliable. The magnetic sensors are state-of-the-art miniature fluxgate sensors. Fluxgate sensors make the AHR500GA sensitive and responsive, with better temperature performance than other technologies such as magneto-resistive sensors.

The AHR500GA Series of products utilize a sophisticated Kalman filter algorithm to allow the unit to track orientation accurately through dynamic maneuvers. The Kalman filter will automatically adjust for changing dynamic conditions without any external user input. No user intervention or configuration is required at power-up.

2 Package Contents

In addition to your AHR500GA sensor product you should have:

- **1 CD with GyroView Software**

GyroView will allow you to immediately view the outputs of the AHR500GA on a PC running Microsoft® Windows™. You can also download this software from Crossbow's web site at <http://www.xbow.com>.

- **1 Digital Signal Calibration/Maintenance Cable.**

This links the AHR500GA directly to a serial port. Only the transmit, receive, power, and ground channels are used. The magnetometer calibration switch will be visible on the connector.

- **1 AHR500GA Installation Manual**

This contains the installation and calibration information for the AHR500GA model type ordered.

3 AHR500GA Description

3.1 AHR500GA Coordinate System

The AHR500GA will have a label on one face illustrating the AHR500GA coordinate system. With the connector facing you, and the mounting plate down, the axes are defined as:

X-axis – from face with connector through the AHR500GA

Y-axis – along the face with connector from left to right

Z-axis – along the face with the connector from top to bottom

This is the default configuration for the generic AHR500GA model. Other coordinate frame orientations are supported given the model type purchased, and these will be reflected in the label as well as through the model configuration number. The axes form an orthogonal right-handed coordinate system. An acceleration is positive when it is oriented towards the negative side of the coordinate axis. For example, with the AHR500GA sitting on a level table, it will measure zero g along the x- and y-axes and +1 g along the z-axis. Gravitational acceleration is directed downward, and thus will be defined as positive for the AHR500GA z-axis.

The angular rate sensors are aligned with these same axes. The rate sensors measure angular rotation rate around a given axis. The rate measurements are labeled by the appropriate axis. The direction of a positive rotation is defined by the right-hand rule. With the thumb of your right hand pointing along the axis in a positive direction, your fingers curl around in the positive rotation direction. For example, if the AHR500GA is sitting on a level surface and you rotate it clockwise on that surface, this will be a positive rotation around the z-axis. The x- and y-axis rate sensors would measure zero angular rates, and the z-axis sensor would measure a positive angular rate.

The magnetic sensors are aligned with the same axes definitions and sign as the linear accelerometers.

Pitch is defined positive for a positive rotation around the y-axis (pitch up). Roll is defined as positive for a positive rotation around the x-axis (roll right). Yaw is defined as positive for a positive rotation around the z-axis (turn right).

The angles are defined as standard Euler angles using a 3-2-1 system. To rotate from the body frame to an earth-level frame, roll first, then pitch, and then yaw.

3.2 Connections

The AHR500GA500 has a male DB-15 connector. The signals are as shown in Table 1.



Table 1 Connector Pin Assignments

Pin	Signal	Electrical Specifications
1	RS-232 Transmit	+/- 4.5 VDC min wrt power ground.
2	RS-232 Receive	+/- 25 VDC max wrt power ground.
3	VDC Power Input	10-40 VDC normal, 9VDC emergency
4	Power Input Ground	
5	No connection	Do not connect
6	No connection	Do not connect
7	RS-422 Transmit + A	2.0 VDC differential output (min) into 100 ohms. Common mode output voltage, 3VDC max.
8	RS-422 Transmit - A	
9	Signal Ground	Capacitive coupling to internal system ground. Should be connected to user's system ground to reduce RS232 and RS422 signal noise.
10	Factory mode pin	Factory reserved; do not connect
11	Factory mode pin	Factory reserved; do not connect
12	Magnetometer calibration input (hard and soft iron cal)	Active: Short to power ground. Inactive: Open circuit. (Internally pulled to +3.3VDC through 10Kohm resistor)
13	Hardware BIT Status	Open collector, requires user pull-up resistor. Max pull-up voltage: +15VDC Max current sink: 10ma.
14	RS-422 Receive + A	Common mode input voltage range: 3VDC wrt power ground.
15	RS-422 Receive - A	
N/A	Case Ground	Electrically connected to I/O connector shell

3.2.1 I/O Cable

The user must provide a shielded cable with the shield connected to the I/O connector shell in order to provide the required EMI protection. The cable sent with the unit is intended to provide the user with the ability to perform a magnetometer calibration, and provide routine magnetometer calibration maintenance of the system, and will not provide adequate shielding.

3.2.2 Power Input and Power Input Ground

The AHRS500GA power requirements are described in the table below. It is designed to operate with either a nominal 14VDC or 28VDC aircraft power system.

Table 2 Electrical Power Input Requirements

Item	Requirement	AHRS500GA specification
1	Input Supply voltage	10-40 VDC
2	Input Supply Current	1 Amp (max)

3.2.3 Case Ground

The case is electrically connected to the I/O connector shell. The shell should be electrically connected to the user's cable shield. The case is isolated from the Power Input Ground, and should be bolted to a good conducting surface that is grounded.

3.2.4 Serial Data Interface

The interface specification is a factory configurable RS-422 or RS-232, also with factory configurable baud rates (see table below) depending on the model configuration chosen. Data output is continuous at a fixed frequency dependant on the baud rate (see table below).

Table 3 Supported BAUD Rates and Output Rates

BAUD Rate	Output Rate
9600	25
19200	50
38400	100
57600	200

The unit has both an RS-232 and RS422 serial interface. During factory configuration, one port is configured as the user data port while the other is

a factory diagnostic port to monitor BIT data. The unit can be configured to allow either port to be the user data port, defaulting the other for BIT diagnostics. The port definition is specified by the model configuration chosen and will be detailed in the model configuration sheet shipped with the unit.

3.2.5 BIT Status Output Pin

The BIT status output pin will become active high if the system is experiencing a failure. The BIT is an open collector signal and requires a pull-up resistor for proper operation.

3.2.6 Magnetometer calibration Input Pin

The AHR500GA has an input pin to control the magnetometer hard-iron calibration function. When this pin is active (low) the unit will collect the data necessary for magnetometer calibration. When it becomes inactive, the calibration data shall be used to compute the hard and soft iron compensation values. During normal operation, no connection should be made to this pin; this pin shall be tied high internally with a pull-up resistor. This feature has been added as a means to perform a Hardiron/Softiron calibration without sending the calibration commands to the unit. Please see Appendix C, for a complete explanation of the Hardiron/Softiron calibration process, and how this pin can be used as a means of implementing the calibration.

3.2.7 No Connection

During normal operation of the AHR500GA, no connection is made to the factory test pin. This pin has an internal pull-up mechanism and must have no connection for the AHR500GA to operate properly.

3.2.8 Quick Digital interface connection

On a standard DB-9 COM port connector, make the connections as described in Table 2.

Table 4 DB-9 COM Port Connections

COM Port Connector		AHR500GA Connector	
Pin #	Signal	Pin #	Signal
2	RxD	1	TxD
3	TxD	2	RxD
5	GND*	4	GND*

*Note: Pin 4 on the AHR500GA is data ground as well as power ground.

Power is applied to the AHR500GA on pins 3 and 4. Pin 4 is ground; Pin 3 should have 10-40 VDC unregulated at 275 mA.

The default serial interface is standard RS-232, model configured baud rate, 8 data bits, 1 start bit, 1 stop bit, no parity, and no flow control, and will output at a model configured output rate.

Crossbow will supply AHR500GA communication software examples written in LabView. Source code for the AHR500GA serial interface can be obtained via the web at <http://www.xbow.com>. The source code has a .vi file format and requires a National Instruments LabView 5.0 or newer license to use.

3.3 Measurements

The AHR500GA Series is designed to operate as a complete attitude and heading reference system. See the “Data Packet Format” section for the actual structure of the data packet.

3.3.1 Attitude and Heading

In angle mode, the AHR500GA acts as a complete attitude and heading reference system and outputs the stabilized pitch, roll, and yaw angles along with the angular rate, acceleration, and magnetic field information. The angular rate, acceleration, and magnetic field values are calculated as described in the sensor section.

The Kalman filter operates in angle mode to track the rate sensor bias and calculate the stabilized roll, pitch, and yaw angles.

The AHR500GA uses the angular rate sensors to integrate over your rotational motion and find the actual pitch, roll, and yaw angles. The AHR500GA uses the accelerometers to correct for rate sensor drift in the vertical angles (pitch and roll); the AHR500GA uses the magnetometers to correct for rate sensor drift in the yaw angle. This is the modern equivalent of an analog vertical gyro that used a plumb bob in a feedback loop to keep the gyro axis stabilized to vertical. The AHR500GA takes advantage of the rate gyros' sensitivity to quick motions to maintain an accurate orientation when accelerations would otherwise throw off the accelerometers measurement of the AHR500GA orientation relative to gravity; the AHR500GA then uses the accelerometers to provide long term stability to keep the rate gyro drift in check.

The AHR500GA uses a sophisticated Kalman filter algorithm to track the bias in the rate sensors. This allows the AHR500GA to use a very low effective weighting on the accelerometers when the AHR500GA is moved. This makes the AHR500GA very accurate in dynamic maneuvers.

The AHRS500GA outputs the stabilized pitch, roll and yaw angles in the digital data packet in angle mode. To convert the digital data to angle, use the following relation:

$$\text{angle} = \text{data} * (\text{SCALE}) / 2^{15}$$

where **angle** is the actual angle in degrees (pitch, roll or yaw), **data** is the signed integer data output in the data packet, and **SCALE** is a constant. **SCALE** = 180° for roll, pitch and yaw.

3.3.2 Sensor Measurements

The analog accelerometer and gyro sensors are sampled, converted to digital data, temperature compensated, corrected for misalignment, and scaled to engineering units. The digital data represents the actual value of the quantities measured. A calibration table for each sensor is stored in the AHRS500GA non-volatile memory. The data is sent as signed 16-bit 2's complement integers. To convert the acceleration data into G's, use the following conversion:

$$\text{accel} = \text{data} * (10 * 1.5) / 2^{15}$$

where **accel** is the actual measured acceleration in G's, **data** is the digital data sent by the AHRS500GA, and **10** is the G Range for your AHRS500GA. (The data is scaled so that 1 G = 9.80 m s⁻².) This maximum G range is a default value.

To convert the angular rate data into degrees per second, use the following conversion:

$$\text{rate} = \text{data} * (800 * 1.5) / 2^{15}$$

where **rate** is the actual measured angular rate in °/sec, **data** is the digital data sent by the AHRS500GA, and **800** is the Angular rate Range of the AHRS500GA. This maximum angular rate is a default value.

3.3.3 BIT Processing

The BIT message in each packet provides comprehensive information into system health. The following information is supplied in the BIT byte fields of the data packet. The table contains the actual bit definition present in the two-byte output BIT field in the angle mode data packet (see section 3.6 below). The description defines the bit's active (1) position.

Table 5 Bit Message Definition

BIT Data	Description	Bit Location
Hard Failure	An unrecoverable failure has occurred	Bit 0
Soft Failure	A soft failure has been detected. A soft failure can be generated by any BIT condition designated “soft”. If the soft failure persists for more than 2100 data packets the Hard Failure bit is turned on and the Soft Failure bit is permanently on.	Bit 1
Not Ready	The system is not ready to use	Bit 2
Power Fail	A power failure has been detected. The system is on hold-up power and is about to lose power.	Bit 3
Comm	A serial port (user) communications error (ex over-run, parity) has been detected.	Bit 4
Reboot Detect	A processor reset was detected possibly due to a watchdog timeout or low-power setting.	Bit 5
Calibration Table	A bad calibration table in flash memory has been detected.	Bit 6
Turn Indicator	A turn has been detected	Bit 8
Algorithm Status	Not ready, waiting for power-up or post sensor saturation	Bits 10,9: 11
	Valid data but in initialization mode	Bits 10,9: 10
	Valid data but using only gyro integration to provide attitude output	Bits 10,9: 01
	Full accuracy data	Bits 10,9: 00
Magnetometer Cal Status	A Hardiron/Softiron calibration is being performed.	Bit 11
Magnetometer Cal Validity	Bad stored Hardiron/Softiron calibration data has been detected	Bit 12
Magnetometer Cal Performance	The Hardiron/Softiron calibration is unsatisfactory	Bit 13

3.4 Commands

The AHR500GA does not have a command structure.

3.5 Data Packet Format

In general, the digital data representing each measurement is sent as a 16-bit number (two bytes). The data is sent MSB first then LSB.

Table 6 AHR500GA Series Data Packet Format

Byte	Data
0	Header (0xAA)
1	Header (0x55)
2	Roll Angle (MSB)
3	Roll Angle (LSB)
4	Pitch Angle (MSB)
5	Pitch Angle (LSB)
6	Heading Angle (MSB)
7	Heading Angle (LSB)
8	Roll Angular Rate (MSB)
9	Roll Angular Rate (LSB)
10	Pitch Angular Rate (MSB)
11	Pitch Angular Rate (LSB)
12	Yaw Angular Rate (MSB)
13	Yaw Angular Rate (LSB)
14	X-Axis Acceleration (MSB)
15	X-Axis Acceleration (LSB)
16	Y-Axis Acceleration (MSB)
17	Y-Axis Acceleration (LSB)
18	Z-Axis Acceleration (MSB)
19	Z-Axis Acceleration (LSB)
20	Model Number (MSB)
21	Model Number (LSB)
22	BIT (MSB)
23	BIT (LSB)
24	Checksum (MSB)

These numbers are sent as a 16-bit signed integer in 2's complement format. The data is sent as two bytes, MSB first then LSB.

Each data packet will begin with a two-byte header (hex AA 55) and end with a two-byte checksum. The checksum is calculated in the following manner:

1. Sum all packet contents *except* header and checksum.
2. Divide the sum by hex FFFF.
3. The remainder should equal the checksum.

The packet also contains the model type configuration number, and the BIT word output. Please refer to section 3.3.3 for details about the BIT word processing.

3.6 Timing

The default AHR500GA data output rate is 100 samples per second. Depending on the model configuration chosen, the system output sample rate can be set to a different constant value.

In some applications, using the AHR500GA's digital output requires a precise understanding of the internal timing of the device. The processor internal to the AHR500GA runs in a loop - collecting data from the sensors, processing the data, and then collecting more data. The data is reported to the user through a parallel process.

The unit goes through three processes in one data cycle. First, the sensors are sampled. Second, the unit processes the data for output. After processing the data, the AHR500GA will make another measurement while presenting the current measurement for output. Third, the unit actually transfers the data out over the RS-232 port.

3.7 Magnetic Heading

Magnetic north is the direction toward the magnetic north pole; true north is the direction towards the true North Pole.

The AHR500GA yaw angle output is referenced to magnetic north. The direction of true north will vary from magnetic north depending on your position on the earth. The difference between true and magnetic north is called declination or magnetic variance. You will need to know your declination to translate the AHR500GA magnetic heading into a heading referenced to true north.

4 AHR500GA Operation

4.1 Normal Operation

The AHR500GA is configured to output data continuously when power is applied. The AHR500GA does not recognize any input serial commands.

4.2 Calibration Operation

The AHR500GA can be commanded to perform a hard/soft iron calibration for the magnetometers using the procedure in Appendix C. Data supplied during normal operation will not be available and the data output should not be used for flight purposes.

4.3 Viewing AHR500GA Data with GyroView

Crossbow includes GyroView software to allow you to directly view the AHR500GA data. Install the GyroView software, connect the AHR500GA to your serial port, apply power to your unit and start taking measurements.

4.3.1 GyroView Computer Requirements

The following are minimum capabilities that your computer should have to run GyroView successfully:

- CPU: Pentium-class
- RAM Memory: 32MB minimum, 64MB recommended
- Hard Drive Free Memory: 15MB
- Operating System: Windows 95, 98, NT4, 2000

4.3.2 Install GyroView

To install GyroView in your computer:

1. Insert the CD "Support Tools" in the CD-ROM drive.
2. Find the GyroView folder. Double click on the setup file.
3. Follow the setup wizard instructions. You will install GyroView and a LabView Runtime Engine. You will need both these applications.

If you have any problems or questions, you may contact Crossbow directly.

4.3.3 Connections

The AHR500GA is shipped with a calibration/maintenance cable to connect the AHR500GA to a PC communications port.

1. Connect the 15-pin end of the digital signal calibration/maintenance cable to the port on the AHR500GA.
2. Connect the 9-pin end of the calibration/maintenance cable to the serial port of your computer.
3. Connect the 15-pin end of the digital signal calibration/maintenance cable to the aircraft mating cable.
4. Bolt the base of the unit to a grounded surface. A good ground is required for EMI and lightning over-voltage protection.

WARNING

Do not reverse the power leads! Applying the wrong power to the AHR500GA can damage the unit; although there is reverse power protection, Crossbow Technology is not responsible for resulting damage to the unit should the reverse voltage protection electronics fail.

4.3.4 Setup GyroView

With the AHR500GA connected to your PC serial port and powered, open the GyroView software (Rev 2.3 or later).

1. GyroView should automatically detect the AHR500GA and display the serial number and firmware version if it is connected.
2. If GyroView does not connect, check that you have the correct COM port selected. You find this under the “DMU” menu.
3. Select the type of display you want under the menu item “Windows”. Graph displays a real time graph of all the AHR500GA data; FFT displays a Fast-Fourier transform of the data; Navigation shows an artificial horizon display.
4. You can log data to a file by entering a data file name. You can select the rate at which data is saved to disk.
5. If the status indicator says, “Connected”, you’re ready to go. If the status indicator doesn’t say connected, check the connections between the AHR500GA and the computer; check the power; check the serial COM port assignment on your computer.

4.3.5 Take Measurements

Once you have configured GyroView to work with your AHR500GA, pick what kind of measurement you wish to see. “Graph” will show you the output you choose as a strip-chart type graph of value vs. time. “FFT” will show you a real-time Fast-Fourier transform of the output you choose. “Navigation” will show an artificial horizon and the stabilized pitch and roll output of the AHR500GA.

Let the AHRS500GA warm up for 90 seconds when first turned on. This allows the Kalman filter to estimate the rate sensor biases. Now you're ready to use the AHRS500GA!

5 Limitations

5.1 Installation

The AHR500GA -202 must be mounted with the mounting plate facing down into the gravitational field for correct operation.

The AHR500GA -202 must be mounted in a location with limited magnetic material near the unit. Refer to the installation manual for detailed instructions.

5.2 Calibration

The AHR500GA -202 must successfully complete a hard iron calibration to reach full accuracy. Refer to the installation manual for detailed instructions.

5.3 Operation

Magnetic material near the AHR500GA

Introduction of large ferrous or magnetic material objects close to the AHR500GA -202, after calibration, will affect the heading performance. Maintain at least 18 inches of distance between moving ferrous metal or magnetic material and the AHR500GA -202.

5.4 Range Limitations

The internal sensors in the AHR500GA -202 are limited to maneuvers of less than 200 degs/dec and less than 10 Gs acceleration in bank, pitch, and heading. Over range of a sensor is indicated in the data packet message to the display system. Over range will start a new initialization cycle of the AHR500GA and will require 90 seconds of straight and level flight to reinitialize the AHR500GA -202.


The AHR500GA -202, like all magnetometer and magnetic compass-based systems, will not perform properly at the magnetic North and South Poles. The AHR500GA -202 will not operate properly in low gravitational fields and magnetic fields encountered during space flight.

6 AHRS500GA Installation

Refer to the AHRS500GA Installation Manual (Doc# 7410-0001-01) for detailed mounting instructions for the AHRS500GA.

7 Appendix A. Mechanical Specifications

The AHRS500GA Installation drawing, 7420-0001-01 should be used.



NOTES UNLESS OTHERWISE STATED:

- 1) INTERPRET DWG. PER ANSI Y14.5M-1994
- 2) CONTROLLING DIMENSION: INCHES
- 3) FINISH: MIL-C-5541 CLASS 3 (YELLOW IRIDITE)

4) 15 POSITION MALE "D" CONNECTOR

8 Appendix B. AHR500GA Output Quick Reference

10 is the G-range of the accelerometers. This is the default maximum range of the accelerometers.

800 is the rate range of the rate sensors. This is the default maximum range of the gyros.

Digital Output Conversion

Data is sent as 16-bit signed integer.

Acceleration

$$\text{Accel (G)} = \text{data} * 10 * 1.5/2^{15}$$

Conversion

$$\text{Angle (}^\circ\text{)} = \text{data} * 180/2^{15}$$

Rate

$$\text{Rate (}^\circ\text{/s)} = \text{data} * 800 * 1.5/2^{15}$$

Magnetic Field

$$\text{Mag (Gauss)} = \text{data} * 1.25 * 1.5/2^{15}$$

9 Appendix C. Hard and Soft Iron Calibration

9.1 Hard/Soft Iron Calibration Requirements

The AHR500GA will need to be calibrated for hard and soft iron compensation before use with the aircraft. Refer to the AHR500GA installation manual for installation calibration.

The AHR500GA will need recalibration whenever ferrous metal components have been replaced or moved relative to the AHR500GA within a 24 inch radius of the unit.

9.2 Hard/Soft Iron Calibration Introduction

The AHR500GA series use magnetic sensors to compute heading. Ideally, the magnetic sensors would be measuring only earth's magnetic field to compute the heading angle. In the real world, however, residual magnetism in the AHR500GA itself and in your system will add to the magnetic field measured by the AHR500GA.

The extra magnetic field can create errors in the heading measurement if they are not compensated. These extra magnetic fields are called hard iron magnetic fields. In addition, magnetic material can change the direction of the magnetic field as a function of the input magnetic field. This dependence of the local magnetic field on input direction is called the soft iron effect. The AHR500GA measures any extra constant magnetic field that is associated with the AHR500GA or your aircraft and corrects for it during the calibration procedure. The AHR500GA can also make a correction for some soft iron effects. The process of measuring these non-ideal effects and correcting for them is called hard iron and soft iron calibration. Calibration will help correct for magnetic fields that are fixed with respect to the AHR500GA. It cannot compensate for time varying fields, or fields created by parts that move with respect to the AHR500GA. The AHR500GA accounts for the extra magnetic field by making a series of measurements. The AHR500GA uses these measurements to model the hard iron and soft iron environment in your aircraft.

9.3 AHR500GA Hard and Soft Iron Calibration Procedure

The hard and soft iron calibration procedure is performed in place on the aircraft using the calibration/maintenance cable provided, a portable PC running Windows, and Gyroview software provided by Crossbow Technology, Inc. A switch on the cable provides a signal input to the AHR500GA commanding it to enter the hard iron calibration process. The aircraft will then need to be rotated through a complete circle(s) while

monitoring the BIT status using the Gyroview software. The calibration software will determine when an adequate set of calibration data has been acquired and notify the user through the BIT status. The entire procedure may take several rotations of the aircraft to collect sufficient data.

For best accuracy, you should do the calibration process with the AHR500GA installed in your system. If you do the calibration process with the AHR500GA by itself, you will only correct for the magnetism internal to the AHR500GA. If you then install the AHR500GA in an aircraft and the magnetic environment is different, you will still see errors arising from the magnetism of the aircraft environment.

9.3.1 Equipment Needed

The following equipment and software is needed to perform the hard and soft iron calibration:

- **1 CD with GyroView Software, Rev 2.3 or later**

GyroView will allow you to immediately view the outputs of the AHR500GA on a PC running Microsoft® Windows™. You can also download this software from Crossbow's web site at <http://www.xbow.com>.

- **1 Calibration/Maintenance Cable.**

This links the AHR500GA directly to a serial port on a PC running Microsoft Windows for installation and maintenance functions independent of the aircraft wiring harness.

- **1 Portable computer**

The computer should be a portable "laptop" style if possible with a serial port and Windows 95/98/2000/XP type operating system. The following are minimum capabilities that your computer should have to run GyroView successfully:

CPU: Pentium-class

RAM Memory: 32MB minimum, 64MB recommended

Hard Drive Free Memory: 15MB

Operating System: Windows 95, 98, NT4, 2000

9.3.2 Installation and Calibration Cable Connections

The AHR500GA is shipped with an installation and calibration cable to connect the unit to a PC communications port.

1. Connect the 15-pin end of the calibration cable to the port on the AHR500GA.

2. Connect the other 15 pin end of the calibration cable to the aircraft cable.
3. Connect the 9-pin end of the cable to the serial port of your computer.
4. The calibration switch on the cable should be set to OFF. Powering up the unit with the switch in the ON position will erase the magnetometer calibration.
5. With the AHR500GA connected to your PC serial port and powered, open the GyroView software.
6. GyroView should automatically detect the AHR500GA and display the serial number and firmware version if it is connected.
7. If GyroView does not connect, check that you have the correct COM port selected. You find this under the “DMU” menu.
8. If the status indicator says, “Connected”, you’re ready to go. If the status indicator doesn’t say connected, check the connections between the AHR500GA and the computer; check the power; check the serial COM port assignment on your computer.
9. Let the AHR500GA warm up for 60 seconds when first turned on. This allows the Kalman filter to estimate the rate sensor biases. Now you’re ready to calibrate the AHR500GA.

9.4 Calibration Process

The BIT status display in GyroView will be used to indicate the progress of the magnetometer compensation calibration. Four bits of the BIT status display are used for evaluating the hard iron calibration:


Bits 9 and 10 comprise a two-bit field that shows the state of the attitude algorithm in the AHR500GA

Bit 11 shows the mag cal mode


Bit 13 shows the mag calibration data status

9.4.1 Starting the Calibration

If the power has been applied less than approximately 90 seconds, the Gyro View BIT display will indicate that the AHR500GA is initializing:




After approximately 90 seconds, the AHRS500GA will complete the initialization mode and change to the ready mode. At this time, the following BIT status should be displayed:




9.4.2 Switch to Mag Cal Mode

Start the magnetic calibration by moving the calibration switch on the calibration/maintenance cable to the ON position. The AHRS500GA will use all the subsequent measurements while the switch is in the ON position to model the magnetic environment. At this time, the following BIT status should be displayed:




9.4.3 Collecting Calibration Data

Make one complete turn, with the aircraft close to level on the tarmac, compass rose, etc. The aircraft does not have to be perfectly level, as the algorithm will compensate for any angle offsets, but running the test with the aircraft as close to level as possible will ease the process. The AHRS500GA monitors the data and calculates when a full turn is completed. At the completion of the full circle, the AHRS500GA will reset itself into initialization mode and apply the estimated magnetometer calibration parameters. The turn indicator bit will come on while the AHRS500GA is being moved through the turn and the GyroView BIT status panel will have the following appearance during the turn:



When the circle is completed, the following Gyro View BIT status should be displayed indicating the unit has made a full turn and is applying the estimated calibration. You should stop the rotation motion once the system status bits show the unit has reinitialized.




9.4.4 Evaluating Calibration Data

At this point, you should also monitor the Mag Cal Data Status bit 13 of the BIT word.


If the magnetometer compensation is adequate, the following BIT status should be displayed:

:




If the Mag Cal Data Status Bit is OFF as shown above, the data collected is adequate for the magnetometer calibration. No further aircraft motion is required. Proceed to the paragraph titled “ Completing the Calibration.”

If the magnetometer compensation data collection is not adequate, the mag cal data status bit (13) will still be ON and the following BIT status will be displayed:




The Mag Cal Data Status Bit ON indicates that the compensation is not yet optimized and more calibration data needs to be collected. It won't usually signal a successful calibration after the first turn, unless the magnetic environment is extremely clean. Wait for the AHRS500GA to complete its initialization. At the end of the initialization, approximately 90 seconds, the following BIT status should be displayed:



Repeat the “collecting calibration data” paragraph above, making another complete turn circle with the aircraft. Always turn the aircraft the same direction as the first turn. After the complete turn, the system will again reinitialize, and apply the latest estimates of the calibration parameters as described in the “Evaluating Calibration Data” paragraph. Continue repeating the cycle of turning the aircraft until initialization mode is indicated, looking at the mag cal data status bit for adequate data, and then waiting for the ready status (~90 seconds) before turning the aircraft again. In this way, the calibration algorithm continues to refine itself until it achieves a successful calibration.

9.4.5 Completing the Calibration

At this point, the AHRS500GA has collected enough data for a good magnetometer compensation calibration. Move the calibration switch on the maintenance/calibration cable to the OFF position. The AHRS500GA will now store these as calibration constants in the EEPROM for use upon subsequent power cycles. The Gyro View BIT status display should look like:



9.4.6 Testing the Calibration

The heading calibration can be tested by comparing the heading output of the AHRS500GA against a known reference (compass or compass markers).

10 Appendix D. Warranty and Support Information

10.1 Customer Service

As a Crossbow Technology customer you have access to product support services, which include:

- Single-point return service
- Web-based support service
- Same day troubleshooting assistance
- Worldwide Crossbow representation
- Onsite and factory training available
- Preventative maintenance and repair programs
- Installation assistance available

10.2 Contact Directory

United States: Phone: 1-408-965-3300 (7 AM to 7 PM PST)

Fax: 1-408-324-4840 (24 hours)

Email: techsupport@xbow.com

Non-U.S.: refer to website www.xbow.com

10.3 Return Procedure

10.3.1 Authorization

Before returning any equipment, please contact Crossbow to obtain a Returned Material Authorization number (RMA).

Be ready to provide the following information when requesting a RMA:

- Name
- Address
- Telephone, Fax, Email
- Equipment Model Number
- Equipment Serial Number
- Installation Date
- Failure Date
- Fault Description
- Will it connect to GyroView?

10.3.2 Identification and Protection

If the equipment is to be shipped to Crossbow for service or repair, please attach a tag TO THE EQUIPMENT, as well as the shipping container(s), identifying the owner. Also indicate the service or repair required, the problems encountered, and other information considered valuable to the service facility such as the list of information provided to request the RMA number.

Place the equipment in the original shipping container(s), making sure there is adequate packing around all sides of the equipment. If the original shipping containers were discarded, use heavy boxes with adequate padding and protection.

10.3.3 Sealing the Container

Seal the shipping container(s) with heavy tape or metal bands strong enough to handle the weight of the equipment and the container.

10.3.4 Marking

Please write the words, "**FRAGILE, DELICATE INSTRUMENT**" in several places on the outside of the shipping container(s). In all correspondence, please refer to the equipment by the model number, the serial number, and the RMA number.

10.3.5 Return Shipping Address

Use the following address for all returned products:

Crossbow Technology, Inc.

41 Daggett Drive

San Jose, CA 95134

Attn: RMA Number (XXXXXX)

10.4 Warranty

The Crossbow product warranty is one year from date of shipment.



Crossbow Technology, Inc.
41 Daggett Drive
San Jose, CA 95134
Phone: 408.965.3300
Fax: 408.324.4840
Email: info@xbow.com
Website: www.xbow.com

SUNSTAR 商斯达实业集团是集研发、生产、工程、销售、代理经销、技术咨询、信息服务等为一体的高科技企业，是专业高科技电子产品生产厂家，是具有 10 多年历史的专业电子元器件供应商，是中国最早和最大的仓储式连锁规模经营大型综合电子零部件代理分销商之一，是一家专业代理和分销世界各大品牌 IC 芯片和电子元器件的连锁经营综合性国际公司，专业经营进口、国产名厂名牌电子元件，型号、种类齐全。在香港、北京、深圳、上海、西安、成都等全国主要电子市场设有直属分公司和产品展示展销窗口门市部专卖店及代理分销商，已在全国范围内建成强大统一的供货和代理分销网络。我们专业代理经销、开发生产电子元器件、集成电路、传感器、微波光电元器件、工控机/DOC/DOM 电子盘、专用电路、单片机开发、MCU/DSP/ARM/FPGA 软件硬件、二极管、三极管、模块等，是您可靠的一站式现货配套供应商、方案提供商、部件功能模块开发配套商。商斯达实业公司拥有庞大的资料库，有数位毕业于著名高校——有中国电子工业摇篮之称的西安电子科技大学（西军电）并长期从事国防尖端科技研究的高级工程师为您精挑细选、量身订做各种高科技电子元器件，并解决各种技术问题。

更多产品请看本公司产品专用销售网站：

商斯达中国传感器科技信息网：<http://www.sensor-ic.com/>

商斯达工控安防网：<http://www.pc-ps.net/>

商斯达电子元器件网：<http://www.sunstare.com/>

商斯达微波光电产品网：[HTTP://www.rfoe.net/](http://www.rfoe.net/)

商斯达消费电子产品网：<http://www.icasic.com/>

商斯达实业科技产品网：<http://www.sunstars.cn/>

传感器销售热线：

地址：深圳市福田区福华路福庆街鸿图大厦 1602 室

电话：0755-83370250 83376489 83376549 83607652 83370251 82500323

传真：0755-83376182 (0) 13902971329 MSN: SUNS8888@hotmail.com

邮编：518033 E-mail:szss20@163.com QQ: 195847376

深圳赛格展销部：深圳华强北路赛格电子市场 2583 号 电话：0755-83665529 25059422

技术支持：0755-83394033 13501568376

欢迎索取免费详细资料、设计指南和光盘；产品凡多，未能尽录，欢迎来电查询。

北京分公司：北京海淀区知春路 132 号中发电子大厦 3097 号

TEL: 010-81159046 82615020 13501189838 FAX: 010-62543996

上海分公司：上海市北京东路 668 号上海赛格电子市场 2B35 号

TEL: 021-28311762 56703037 13701955389 FAX: 021-56703037

西安分公司：西安高新开发区 20 所(中国电子科技集团导航技术研究所)

西安劳动南路 88 号电子商城二楼 D23 号

TEL: 029-81022619 13072977981 FAX:029-88789382