Model 3156

Care a result of the care of t

Tension/Compression Canister Load Cell

DESCRIPTION

The Model 3156 fatigue-resistant load cells are extremely resistant to extraneous bending and side loading forces. The structure virtually eliminates bending strains at the strain gage,

minimizing the primary cause of load cell failure. Dual bridge option available for feedback control and redundancy.

FEATURES

- English threads (metric configuration available: 3156-133)
- Resist fatigue failure
- Minimize bending strains
- Dual bridges available on all models
- Multi-beam structure design
- Enhanced resistance to side loads and bending moments

Model 3156

PERFORMANCE SPECIFICATIONS

Characteristic	Measure
Load range ¹	100K, 200K, 500K, 750K N
Non-linearity	±0.2 % of rated output
Hysteresis	±0.2 % of rated output
Repeatability	±0.05 % of rated output
Output @ rated capacity	±2 mV/V (nominal)
Operation	Tension/compression
Resolution	Infinite
Standard calibration	Tension (+) and compression (-)

ENVIRONMENTAL SPECIFICATIONS

Characteristic	Measure
Temperature, operating	-54 °C to 93 °C [-65 °F to 200 °F]
Temperature, compensated	21 °C to 77 °C [70 °F to 170 °F]
Temperature effect, zero	±0.003 % of rated output/°F
Temperature effect, output	±0.003 % of reading/°F

ELECTRICAL SPECIFICATIONS

Characteristic	Measure
Strain gage type	Foil
Excitation (maximum)	30 Vdc or Vac RMS
Insulation resistance	> 5000 mOhm @ 50 Vdc
Bridge resistance (tolerance)	350 ohm
Number of bridges	1 or 2
Zero balance	±1.0 %
Electrical termination	MS-3102E-14S-5P


MECHANICAL SPECIFICATIONS

Characteristic	Measure
Static overload capacity	150 % of nominal capacity
Material	Carbon steel
Fatigue life (0 to full fatigue load)	100 x 10 ⁶ cycles
Fatigue life (full fatigue tension to compression)	50 x 10 ⁶ cycles
Natural frequency	See table

WIRING CODES

Wire	
Red	(+) excitation
Black	(-) excitation
Green	(+) output
White	(-) output

TYPICAL SYSTEM DIAGRAM



Mating Connectors & Cables

064-LW13621 Mating connector
7200-76-XX* Mating connector and six conductor cable
(unamplified unit with sense leads but not shunt cal)
7200-75-XX** Mating connector (MS - 5 pin) and four conductor cable
(unamplified sensor without sense leads)
7200-111-XX** Mating connector (MS - 5 pin) & 6 conductor cable
for connection to 7541

7200-110-XX** Mating connector (MS - 5 pin) & 4 conductor cable
for connection to 7541

* XX represents length in feet 100ft maximum ** XX represents length in feet 20ft maximum

Honeywell

Tension/Compression Canister Load Cell

NATURAL FREQUENCY


Nominal lo	ominal load limit apacity F _z			Static extran	eous load limi			
lb	N	Static overload capacity (% of nominal capacity)	Fatigue capacity (% of nominal capacity)	Shear F _x or F _y (lb)	Bending M _x or M _y (lb-in)	Torque M _z (lb-in)	Deflection at nominal load limit (in)	Ringing frequency (Hz)
25K	100K	150	100	2K	68K	10K	0.003	2100
50K	200K	150	100	6K	130K	20K	0.003	3000
100K	500K	150	100	10K	220K	85K	0.003	4200
150K	750K	150	100	20K	220K	85K	0.003	4800


MOUNTING DIMENSIONS

Model	A cm [in]	B cm [in]	C cm [in]	D cm [in]	E cm [in]	F cm [in]	G cm [in]
3156	17,78 [7]	13,97 [5.50]	8,89 [3.50]	5,41 [2.13]	12,07 [4.75]	2,87 [1.13]	13,84 [5.45]

H cm [in]	J cm [in]	K cm [in]	L cm [in]	M cm [in]	N cm [in]	P cm [in]	*R cm [in]
9,12 [3.59]	8,89 [3.50]	0,79 [0.31]	0,95 [0.38]	5,08 [2]	3,18 [1.25]	M20 x 2.5 [3/4-10]	M52 x 2 [2-12]

- * 3156-133 P and R are metric thread measures
- * 3156 standard P and R are English thread measures





R传感与控制 http://www.sensor-ic.com/ TEL:0755-83376549 FAX:0755-83376182 E-MAIL:szss20@163.com Model 3156 Tension/Compression Canister Load Cell

NOTES


1. This unit calibrated to Imperial (non-Metric) units.

Warranty. Honeywell warrants goods of its manufacture as being free of defective materials and faulty workmanship. Honeywell's standard product warranty applies unless agreed to otherwise by Honeywell in writing; please refer to your order acknowledgement or consult your local sales office for specific warranty details. If warranted goods are returned to Honeywell during the period of coverage, Honeywell will repair or replace, at its option, without charge those items it finds defective. The foregoing is buyer's sole remedy and is in lieu of all warranties, expressed or implied, including those of merchantability and fitness for a particular purpose. In no event shall Honeywell be liable for consequential, special, or indirect damages.

While we provide application assistance personally, through our literature and the Honeywell web site, it is up to the customer to determine the suitability of the product in the application.


Specifications may change without notice. The information we supply is believed to be accurate and reliable as of this printing. However, we assume no responsibility for its use.

For more information about Sensing and Control products, visit www.honeywell.com/sensing or call +1-815-235-6847 Email inquiries to info.sc@honeywell.com



• DO NOT USE these products as safety or emergency stop devices or in any other application where failure of the product could result in personal injury.

Failure to comply with these instructions could result in death or serious injury.



- The information presented in this catalogue is for reference only. DO NOT USE this document as product installation information.
- Complete installation, operation and maintenance information is provided in the instructions supplied with each product.

Failure to comply with these instructions could result in death or serious injury.

Sensing and Control Automation and Control Solutions Honeywell 1985 Douglas Drive North Golden Valley, MN 55422 USA +1-815-235-6847

Honeywell

008645-1-EN IL50 GLO

Copyright @ 2008 Honeywell International Inc. All rights reserved.